
Connecting Your New DOCSIS Modem

Step 1

• Disconnect the cables from your old modem including the Power, Telephone, Ethernet and FOCUS Broadband Cable.

Step 2

- Connect the FOCUS Broadband Coax Cable from the Coaxial wall outlet to the new modem.
- · Turn tightly with fingers, then 1/8 turn with wrench until snug.
- · Plug the new modem into the power outlet.



Step 3

- · Allow 10 minutes for the modem to boot up and recieve updates. The modem may reboot during this time.
- · If you subscribe to Premium Wi-Fi with Plume Pods, connect one end of the Ethernet Cable to the modem's LAN (yellow) Port and the other end to the Wi-Fi Pod. This may connect to a computer if applicable.
- · Make sure the Wi-Fi Pod is plugged into the power outlet.

Step 4 (Phone Customers Only)

· Connect one end of the Phone Line to the Telephone Port 1 and the other end to the Phone or the Phone Jack.

